


Hisense

USER'S OPERATION MANUAL

MODEL:HR6CF146
HR6CF206
HR6CF307



Before operating the unit, please read this manual thoroughly and retain for future reference

IMPORTANT: the refrigerant isobutene(R600a) is contained within the refrigerant circuit of the appliance, a natural gas with a high level of environmental compatibility, which is nevertheless flammable.

IMPORTANT: before you install your appliance **PLEASE CHECK FOR ANY DAMAGE OR MARKS.** If you find that the appliance is damaged or marked you must report this within 7 days if you wish to claim for the damaged marks under the manufactures warranty.

This does not affect your statutory rights.



is fire warning sign. Caution: risk of fire.

Service Note

This appliance employs Hydrocarbon Refrigerant type R600a.

It is hazardous for anyone other than an Authorized Service Person to service this applian.

In Queensland the authorized Service Person **MUST** hold a Gas Work Authorization for hydrocarbon refrigerants to carry out servicing or repairs which involve removal of covers.

INSTRUCTION MANUAL

SAFETY PRECAUTIONS 1

To ensure proper use, please thoroughly study these SAFETY PRECAUTIONS before operating the appliance.













The purpose of the safety precautions in this manual is to minimize risks that could cause serious damage and injury to you or other persons. The safety precautions are divided into WARNINGS and CAUTIONS. Cases where improper handling of the unit could lead to death or serious injury are listed under the ⚠ WARNING heading. However, the cases listed under the ⚠ CAUTION heading could also lead to serious results. To ensure the safety, adhere strictly to both types of safety precautions.

⚠ WARNING Improper handling of the unit could lead to death or serious injury.

Text set off by the exclamation mark **!** contains information that should be strictly adhered to. After reading the instruction manual, store it in an easily accessible place where the user(s) of this appliance can easily find it.

PRECAUTIONS FOR USE



















⚠ WARNING

 <p>DONT TAMPER</p> <p>All repairs, disassembly and modifications should be performed only by qualified technicians. Attempting to perform these yourself could result in a fire, malfunction, and injury.</p> 	 <p>ELECTRICAL SHOCK HAZARDS</p> <p>Never splash water directly onto the product or wash with water as short-circuit and electrical leakage could result.</p> 
 <p>DANGER OF EXPLOSION</p> <p>Never put flammable or volatile substances into the unit as explosion and fire could result.</p> 	 <p>PROHIBITED</p> <p>Do not damage, modify, excessively bend, strain, twist or bundle up the power cord. Also, placing heavy objects the power cord or squeezing it in a tight place could damage it, possible resulting in electrical shock or fire.</p> 
 <p>PROHIBITED</p> <p>Use a dedicated wall outlet. Do not use extension cords or convenience receptacles as this could result in electrical shock, overheating and a fire.</p> 	 <p>FLAMMABLE</p> <p>Never use flammable spray cans or leave flammable substances near the unit. Sparks from electrical switches could result in explosion and fire.</p> 

INSTRUCTION MANUAL

SAFETY PRECAUTIONS 2

⚠ WARNING

<p> Do not store bottles and cans in the unit. The contents could freeze and the containers break causing injury.</p> <p></p>	<p> The unit is intended for storage of frozen foods. Storage of items other than the intended could have an adverse affect on the items stored in the unit.</p> <p> Frozen foods</p>
<p> For indoor use only. Using the unit in a location exposed to rain could result in electrical leakage and electrical shock.</p> <p></p>	<p> Never place heavy objects or items containing water on top of the unit. Containers filled with Water could fall and cause injury. Furthermore, the spilled water could deteriorate the insulation of electrical components and result in electrical leakage.</p> <p></p>
<p> Install the unit in a location where the floor is sturdy enough to support the load of the unit. If the floor is not sturdy enough or installation is incorrectly performed, the unit could tip over and cause personal injury.</p> <p></p>	<p> CAUTION AGAINST EXPLOSION</p> <p>If you find a gas leakage, please don't touch the chest freezer, and close gas and open the door for ventilation. A gas leakage could cause an explosion, fire, and injury.</p> <p></p>
<p> When you dispose of refrigerators and freezers remove any doors. Children can suffocate if they get trapped inside. This refrigerator contains insulation formed with flammable blowing gases. Avoid safety hazards by carefully disposing of this appliance. Please contact your local council and seek an environmentally friendly solution.</p>	<p> Keep away from hot air sources Cooling performance is reduced if the unit is placed near heat sources such as hot plates and stoves and if it is exposed to direct sunlight.</p> <p></p>
<p> Leave disassembly and disposal of the unit to qualified experts.</p> <p></p>	<p> When not in use please store the unit in a location away from children. Please take necessary precautions to keep the door opened to avoid accidental entrapment inside the compartment.</p>

INSTRUCTION MANUAL

SAFETY PRECAUTIONS 3

⚠ CAUTION

Sufficient ventilation is required to ensure your freezer operates at optimum high efficiency and with lowest possible power consumption, Therefore you are required to place your appliance in a position with adequate clearance. We recommend you place your appliance at 100mm away from the wall to the back of your appliance, 200mm from the side clearance and 300mm from the top of your appliance. A clearance space of 160 degrees is required for the appliance door.




If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.




Never hang from the door or climb onto the unit.

PROHIBITED




DISCONNECT
POWER CORD
PLUG FROM
WALL OUTLET

Disconnect the power cord plug from the wall outlet before moving the unit and make sure that the power cord is not damaged during transport. A damaged power cord could result in electrical shock and/or fire.




Never touch the power cord plug, other electrical components, or operate the switch with wet hands. Electrical shock could result.

PROHIBITED




PROHIBITED


Never use if the power cord or plug is damaged or the plug cannot be firmly seated in the receptacle sockets as electrical shock, short-circuit and fire could result.



When disconnecting the power cord plug from the wall outlet, hold at the plug main body close to the outlet. Pulling the cord could cause wire breakage, causing overheating and fire.



Make sure that the unit does not tip over or fall when it is moved. A falling unit could cause serious injury.



INSTRUCTION MANUAL

HOW TO USE

BEFORE USE

Remove shipping packaging, tape, etc. and leave the lid open for ventilation for a while. The unit is cleaned before shipment. However, clean the compartment interior once after delivery. Following installation, refrigeration will start about 10 minutes after operation is started. Operate for about 2 hours to cool the freezer compartment before placing items in the freezer.

WAIT 5 MINUTES OR MORE BEFORE RE-STARTING

Restarting the unit immediately after it has been turned off may cause fuses to blow and activate the circuit-breaker, the compressor may be overloaded, and/or other damage may occur.


DEFROSTING

When 5mm of frost forms in the freezer, for maximum efficiency defrosting is required, you could shave off the excess or defrost completely. If you defrost completely, please do as follows:

- 1.) Empty the contents & disconnect the power cord;
- 2.) Shaving the frost whilst thawing will shorten the defrost time;
- 3.) Then drain, wipe & clean the inside with a soft cloth.



Do not use a hammer, knife or bottle to chisel any part of the freezer. Use a plastic scraper to prevent damaging the inside lining and evaporator.



INSTRUCTION MANUAL

CLEANING



To prevent any electrical shock hazards or injury, always disconnect the power cord plug from the wall outlet before cleaning.


1 EXTERIOR AND COOLER COMPARTMENT

Wipe with a soft, dry cloth. If very soiled, wipe with a cloth that has been moistened with a detergent. Then dry off with a clean moist cloth.



WARNING: Do not splash water directly onto the freezer and do not wash with water. Short-circuit and electrical shock could result.

For maximum efficiency keep the freezer clean at all times. To prevent damage to plastic parts and lacquer coating do not clean your appliance with hot water diluent, petrol, alcohol, kerosene, washing powder, cleanser, alkaline detergent, acid, chemical cloth, etc.



IN CASE OF THE FOLLOWING

1 POWER FAILURE

Sudden power failure

Keep opening and closing of the door to a minimum to prevent cold air from escaping from the freezer compartment. Covering exterior glass surfaces with a blanket, etc. will further help to maintain a low temperature.

Announced power suspension

In case of a long power suspension, place dry ice in the freezer compartment.

Keep opening and closing of the door to a minimum.

Avoid placing new items in the freezer as this will raise the temperature inside the compartment.

2 WHEN NOT USED FOR A LONG PERIOD

Remove all items from the compartment and disconnect the power cord plug from the wall outlet.

Clean the compartment interior and wipe away all water. To prevent mold formation and bad smell, leave the door open to dry the compartment completely.

3 WHEN NOT USED TEMPORARILY


Clean the compartment interior and wipe away all water.

Place an object in between the door and outer casing to prevent the door from closing.

Keep children away from playing with the unit - entrapment could result.

PART NAMES AND FUNCTIONS

Model NO: HR6CF146、HR6CF206




Never touch the interior of the Freezer Chamber or frozen foods in the compartment with wet hands as this could result in frostbite.



The above image is for reference only, configuration is subject to actual product.

PART NAMES AND FUNCTIONS

Model NO: HR6CF307




Never touch the interior of the Freezer Chamber or frozen foods in the compartment with wet hands as this could result in frostbite.



The above image is for reference only, configuration is subject to actual product.

TEMPERATURE ADJUSTMENT

- To adjust the temperature inside the freezer compartment, adjust the temperature control dial on front-bottom side of the chest freezer. Normally use chest freezer with temperature Mid.
- If the cooling performance is inadequate, turn the temperature control dial in the direction of Colder. If too cold, turn dial in direction of Cold.
- When you stop running temporarily, please turn the temperature control dial in the direction of Off.




SPECIFICATIONS

Product Name	Chest Freezer					
Product No.	HR6CF146			HR6CF206		
Capacity	145L			205L		
Outer Dimensions (mm)	Width	Depth	Height	Width	Depth	Height
	727	560	823	947	560	823
Performance	Freezer compartment temperature: $-18\text{ }^{\circ}\text{C}$; Conditions: Ambient temperature $43\text{ }^{\circ}\text{C}$, unloaded state, not exposed to direct sunlight.					
Net Weight	30kg			34kg		

SPECIFICATIONS

- To adjust the temperature inside the freezer compartment, adjust the temperature control dial on front-bottom side of the chest freezer. Normally use chest freezer with temperature Mid.
- If the cooling performance is inadequate, turn the temperature control dial in the direction of Colder. If too cold, turn dial in direction of Cold.
- When you stop running temporarily, please turn the temperature control dial in the direction of Off.



SPECIFICATIONS

Product Name	Chest Freezer		
Product No.	HR6CF307		
Capacity	306L		
Outer Dimensions (mm)	Width	Depth	Height
	1126	670	842
Performance	Freezer compartment temperature: $-18\text{ }^{\circ}\text{C}$; Conditions: Ambient temperature $43\text{ }^{\circ}\text{C}$, unloaded state, not exposed to direct sunlight.		
Net Weight	44kg		




The specifications may change, please refer to the circuit name plate on the back of your chest freezer.

INSTRUCTION MANUAL


TROUBLESHOOTINGS

Please check the following items if you encounter problems with the unit. If the problem continues after taking the proper remedial actions, disconnect the power cord plug from the wall outlet. Transfer the items stored in the freezer to another freezer. Then contact the service provider listed in the warranty card, and be ready to provide information as listed in "REQUIRED INFORMATION" below.



To prevent any electrical shock hazards, do not disconnect the power cord plug from the wall outlet with wet hands.

CAUTION

No refrigeration at all	Is the power supply interrupted? Is the power cord plug disconnected from the wall outlet? Are the power fuses blown and/or the circuit breaker activated? The temperature control dial in the direction of Colder.if too cold,turn dial in direction of Off?
Inadequate refrigeration	Is the place of installation badly ventilated? Is the freezer exposed to direct sunlight, placed near a heater or stove? Are the lids opened and closed frequently? Are items stocked beyond the load line? The temperature control dial in the direction of Colder.if too cold,turn dial in direction of Cold? Much frost forms in the chest freezer?
Excessive noise	Is the floor underneath the freezer sturdy enough? Is the unit shaking and rattling? Is the rear panel of the unit contacting a wall, etc.? A container or something is behind the chest freezer? The compressor will generate a rather loud sound for a while after operation is started. The noise will cease together with refrigeration.
Condensation on cooler exterior	Condensation may condense on the exterior and door during hot and humid days or depending on the place of installation. This occurs when the humidity is high and water particles in the air contact cold surfaces. This is normal. wipe away condensation with a dry cloth.
The circumference of chest freezer feels hot	Especially in warmer conditions or startup, the circumference of chest freezer feels hot. This is because the chest freezer incorporates a pipe for radiating and preventing condensation. The heat does not affect the contents in the freezer. <div style="text-align: right; margin-top: 10px;">  </div>

This appliance will sometimes stop running when the thermostat turns off.

REQUIRED INFORMATION

- | | |
|--|---|
| ① Nature of malfunction
(as accurately as possible) | ④ Customer's name, address,
phone number |
| ② Product number | ⑤ Year and date of purchase |
| ③ Serial number | } (inscribed on badge) |

HISENSE WARRANTY TERMS AND CONDITIONS

Washing Machine and Refrigerator

1.HISENSE Australia will provide parts and labor to you the Customer as set out herein.

2.Nothing in the warranty, limits any rights you may have under the trade practices act or any other Commonwealth or State Legislation. Such rights cannot be changed by the conditions in this warranty. Subject to the conditions below this appliance is warranted by Hisense and/or its Agents to be free from defects in materials and workmanship for a period of 36 months from the date of purchase ("Warranty period").

The inverter motor of washing machines has part replacement warranty of 11 years in total. The inverter motor parts only warranty does not include labor costs and must be verified by Hisense certified service Agent.

3.This warranty: -

- a. covers products purchased as NEW, manufactured for use in Mainland Australia and Tasmania;
- b. commences from the date of purchase as listed on the Customers invoice;
- c. provides for the labour and replacement parts necessary to maintain your product in good operating condition as specified in this warranty however, if repair is needed because of product failure during normal usage, Hisense has the option to repair or replace the defective product or part of the product with a product or part of the product of like kind and quality and a replacement part may be new or reconditioned of like kind and quality and may cost less than the original product purchased and no charges or refunds will be made based on the replacement product cost difference;
- d. applies only to the original purchaser and cannot be transferred;
- e. is only applicable when your appliance is used in a domestic environment;
- f. covers products for commercial purposes for a period of 90 Days from the date of purchase.

4.Product Identification

- a. Hisense reserves the right to reject claims for any services or work where the Customer requesting such work or services from Hisense and/or its agents cannot produce for verification the serial number and the proof of purchase as per original purchase invoice.
- b. The warranty will be voided if any Serial Number sticker provided to be placed on the equipment is damaged, modified or removed.
- c. In the event that a request for repair is made against a warranty where the Serial Number sticker is not attached to the product or the customer cannot produce for verification the original invoice, the repairer will not perform any repairs on the product and the Customer will be charged a service call-out fee.

5.What is covered by this warranty

- a. The equipment is covered for faulty workmanship on parts that have failed under normal use which are contained within the product.
- b. Hisense and/or its Agents will decide if there are any defects in the material and/or workmanship
- c. This warranty is only applicable for repairs on declared equipment carried out within Mainland Australia and Tasmania

6.What is not Covered by this warranty (excluded):-

- a. any damage or failure:
 - i. of equipment due to the product being inadequately serviced or maintained as per manufacturer's recommendations;
 - ii. resulting from environmental conditions including and not limited to dirt, dust, rodents, insects, rust, corrosion, salt built-up, of any part of the product including its parts; or
 - iii. resulting from excessive use "fair wear and tear";
 - iv. resulting from poor installation including and not limited to positioning and externally fitted equipment such as plumbing and drainage, or incompatibility of connected equipment;
 - v. to the product caused by overheating as a result of sitting or positioning of the equipment, where there is not provision for adequate ventilation, drainage or a dust free environment;
 - vi. caused if your appliance has been dismantled, repaired or serviced by any person other than someone authorized by Hisense;
 - vii. to a product or components, caused by power surges or spikes, including and not limited to, mains power and telecommunications connections, or to other unspecified sources, incorrect power current, voltage fluctuation, amperage fluctuation, rust or corrosion;

viii. Any form of physical damage of unknown cause, including snapped, damaged or broken parts, collision with another object, use of which it is not designed, negligence, accident or deliberate misuse, theft, abuse, vandalism, flood, fire, earthquake, electrical storms or any other act of God, any war related events or terrorism.

- b. costs of attendance and testing where no mechanical or electrical failure is identified;
- c. initial setup and installation of the product;
- d. Normal maintenance costs and costs incurred through the installation of items listed as requiring periodic replacement;
- e. products with removed or altered serial numbers;
- f. consumables such as but not limited to bulbs/globes, batteries, remote controls or filters;
- g. removal repair or reinstallation of internal component not performed by or approved by Hisense authorized service centre;
- h. cosmetic or structural items;
- i. Any failures due to the interference from or to other products and/or sources.

7.The Warranty Ceases if: -

- a. The product ceases to carry the original manufacturer's serial number or is sold at an auction;
- b. The product is rented;
- c. Damage to the product has occurred as listed in point 6.
- d. Failure to pay monies owing on invoices as a result of non-warranty work been carried out at the request of the end user as per point 15.

8.Neither Hisense nor its representatives provide loan equipment under the terms of this warranty.

9.Our goods come with guarantees that cannot be excluded under the Australian Consumer Laws. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

10.Unauthorized access to the internal hardware or firmware of the product will void this warranty.

11.Replacement items are "Like for like" and is not "new for old" and does not indicate in any way that a faulty product will be replaced with a new part or unit. "Like for like" may either be a quality checked (QC) refurbished or reconditioned unit of the same or equivalent model, size, specifications or features.

12.If your product is 130 litres capacity or under or if you reside outside of the service coverage area this warranty does not cover the costs of transportation or travel expenses to and from your home. Our service coverage area includes a 25km radius of the nearest Hisense authorised retailer or 25km from the Hisense authorised service agent.

13.Hisense accepts no liability for items that are lost, damaged, or stolen as a result of freight, transport or storage. If you are required to transport the appliance to an authorized service centre, you must ensure that it is securely packed and insured.

14.On Public Holidays or other periods when regular business and wholesale operations are temporarily ceased, repairer availability and warranty response times may extend beyond the standard response times due to the availability of repairers and parts.

15.Any repair performed on a product under the warranty where no fault can be found, or the item is deemed by Hisense, or an authorized Hisense agent, to be not faulty under this warranty, or the repair or fault is not covered under the warranty, a No Fault Found fee is payable by the warranty holder of a minimum of \$125 inc GST.

16.Any repairs or services required that are outside of the terms and conditions of the warranty can be carried out at the request of the customer or due to site attendance were fault is not covered under warranty as the product not been installed or setup correctly; a credit card may be required prior to the commencement of such services.

WARRANTY CLAIMS PROCEDURE

Please retain this portion for
your records

36 MONTHS IN HOME REPAIR WARRANTY*

Hisense Australia will provide its nearest service centre for repairs under warranty. You will need to ensure that you have already called Hisense Warranty Centre and received a JOB NUMBER.

Any questions call our hotline on **1800 447 367**

PLEASE REFER TO THE TROUBLESHOOTING GUIDE AT THE END OF THIS MANUAL

Service Procedure

Please have your **proof of purchase, model, and serial number** ready. To receive service, you are required to:

Call **1800 447 367** between **8:30AM – 7:30 PM Mon. to Fri. and 9AM – 5PM Sat and Sun** exc public holidays.

When calling please ensure you have

- 1. Your serial number**
- 2. Proof of purchase**
- 3. and be in front of the product**

You are required to fax or email your original invoice prior to processing your warranty claim.

*Within the nominated service coverage area refer to item 11 in the terms and conditions.

Hisense